



Fitting Guide for Mesh Fronted Box for Stone



1. The box is labelled indicating the species the box is designed for (bat box illustrated) and the top of the box i.e. the right way up.
2. The entrance hole has been made slightly larger than required to allow some leeway in fitting the bricks / brick slips to the front of the box. Final aperture sizes required are: -
 - Bat slot or crescent max. 15mm high
 - Swift hole / slot should be 30mm high x 80mm wide
 - Tits 28 – 33mm diameter hole
 - Sparrows 36mm diameter hole
 - Starling 46mm diameter hole
3. Place the box on the stonework at the desired height and location. Set the box back from the front face of stonework as much as the depth of the wall allows, then build up stonework around sides and in front of the box, making the entrance as you go. Use plenty of mortar to secure the stone to the front and sides of box, cutting stone as required.

Note: The box front will not be removable as the stone will prevent this. The box will still be used - the front is normally only removed for monitoring.

