



## Fitting Guide for Brick Fronted Box

1. The box is labelled indicating the species the box is designed for (swift box shown) and the top of the box i.e. the right way up.
2. Just prior to laying, place the box on the ground, face up, to fill the joints. (Filling the box once built into the wall can place unwanted pressure on the newly constructed wall). Either with a finger pointer or a pointing gun, ensure all joints are as full as possible, including the joint between the bricks and the plastic perimeter edge as shown below.



*Box illustrated is in stretcher bond; should your order be made for quarter bond i.e. English / Flemish, closures will be included for fitting at either end of the box.*

3. Check again that the box is the right way up and set into the host wall at the desired height. Rub up or point box when pointing / rubbing up the rest of the surrounding brickwork.
4. If the front is to be removable, leave the outer perimeter of the box showing in the mortar joints so that you see a faint thin black line. This makes future removal of the front possible.

Note: any residual dust on the face from the cutting and drilling process will wash off in the rain.

